

PROGRAMMA

_ora.

_onderhoudsadvies

_houtsoort	Gerecycleerd Teak
_herkomst	Azië
_kleur (mogelijkheid)	Gerecycleerd Teak - Crea Copper
_overige materialen	MDF / Plaatmateriaal / Oud Teak / Teak / Metaal (onderstellen)
_afwerking	Topcoat op waterbasis

_algemene tips en advies

Hout werkt: het zet uit en krimpt. De mate waarin dat gebeurt, is afhankelijk van de luchtvochtigheid en temperatuur van de ruimte waarin het meubel staat. De ideale luchtvochtigheid ligt tussen de 55% en 65%. De ideale temperatuur is 20°C. Wijkt de situatie hier teveel van af of schommelt deze teveel, dan kan het hout gaan scheuren of kromtrekken. Plaats een meubel daarom dan ook niet dicht bij een warmtebron of airco installatie.

Vermijd (direct) zonlicht: Kleuren worden hierdoor sneller dof en de lak of olie waarmee het meubel behandeld is, slijt sneller af waardoor de kans groter is op schade door normaal dagelijks gebruik. Gebruik daarbij ten alle tijden onderzetters en indien er geknoeid wordt, neem dit direct op met een schone doek. Plaats geen hete potten en/of pannen op meubelen.

_periodiek onderhouds- / reinigingsadvies

Dagelijks onderhoud: Afdoen met een licht vochtige doek en daarna met een droge katoenen doek nawrijven. Vermijd ten alle tijden bijtende, schurende en ammonia houdende middelen.

Periodiek onderhoud: 1 a 2 maal per jaar het meubel (let op: enkel van toepassing op de teak bovenbladen en deurfronten) reinigen met Woodcleaner en behandelen met Mat Polish (Beide producten zijn van Oranje B.V.).

COLLECTION

_ora.

_maintenance advice

_type of wood	Recycled Teak
_origin	Asia
_color (options)	Recycled Teak - Crea Copper
_other materials	MDF / Plate material / Old Teak / Teak / Metal (carriage)
_finishing	Topcoat on waterbase

_general tips and advice

Wood shrinks and expands due to external influences like humidity and temperature. A humidity of 55% to 65% and a constant room temperature of 20°C are the ideal conditions. Large differences in humidity and temperature can cause the wood to crack. If you have a room and/or rooms with varying levels of humidity, we advice to use a humidifier to help stabilize the general level of humidity throughout the whole year. It is important not to place your furniture directly next to a heating source or airconditioning. In addition to this, avoid placing furniture in (direct) sunlight. Colors will fade sooner and lacquer and/or varnishes will wear off sooner which increases the likelihood of damages by normal daily use. Always use coasters and if you spill something, make sure to wipe this off as soon as possible. Also don't place any hot items on the furniture.

_periodic maintenance / cleaning advice

Daily maintenance: Clean with a slightly damp cloth and dry the surface with a dry towel. Avoid aggressive and ammonia containing substances at all times when cleaning.

Periodic maintenance: Clean your furniture item (attention: only the teak tops and doorfronts) 1 or 2 times per year with Woodcleaner & treat it with Mat Polish (Both products are from Oranje B.V.).