

PROGRAMMA _soria.

_onderhoudsadvies

_reinigen	Natural Wood Cleaner
_onderhouden	Wood Matt Polish
_afwerking	Gelakt

_algemene tips en advies

Hout werkt: het zet uit en krimpt. De mate waarin dat gebeurt, is afhankelijk van de luchtvochtigheid en temperatuur van de ruimte waarin het meubel staat. De ideale luchtvochtigheid ligt tussen de 55% en 65%. De ideale temperatuur is 20°C. Wijkt de situatie hier teveel van af of schommelt deze teveel, dan kan het hout gaan scheuren of kromtrekken. Plaats een meubel daarom ook niet te dicht bij een warmtebron of airco installatie. Vermijd (direct) zonlicht: Kleuren worden hierdoor sneller dof en de lak of olie waarmee het meubel behandeld is slijt sneller, waardoor de kans groter is op schade door normaal dagelijks gebruik. Gebruik daarbij te allen tijde onderzetters en indien er toch geknoeid wordt, neem dit direct op met een schone doek. Plaats geen hete potten en/of pannen direct op meubelen.

_periodiek onderhouds-/reinigingsadvies

Dagelijks onderhoud: afdoen met een licht vochtige doek en daarna met een droge katoenen doek nawrijven. Vermijd te allen tijde bijtende en ammonia houdende middelen.

Periodiek onderhoud: 2 à 3 maal per jaar het meubel reinigen met Natural Wood Cleaner en behandelen met Wood Matt Polish om het meubel te beschermen. Beide producten zijn van Oranje B.V.

COLLECTION _soria.

_maintenance advice

_cleaning	Natural Wood Cleaner
_maintenance	Wood Matt Polish
_finishing	Varnished

_general tips and advice

Wood shrinks and expands due to external influences like humidity and temperature. A humidity of 55% to 65% and a constant room temperature of 20°C are the ideal conditions. Large differences in humidity and temperature can cause the wood to crack. If you have a room and/or rooms with varying levels of humidity, we advice to use a humidifier to help stablize the general level of humidity throughout the whole year. It is important not to place your furniture too close to a heating source or airconditioning. In addition to this, avoid placing furniture in (direct) sunlight. Colours will fade sooner and lacquer and/or varnishes will wear off sooner, which increases the likelihood of damage by normal daily use. Always use coasters and if you do spill something, make sure to wipe it with a clean cloth as soon as possible. Also don't place any hot items directly on the furniture.

_periodic maintenance/cleaning advice

Daily maintenance: A damp cloth and mild dish soap are usally all you need to clean your furniture. After cleansing, rinse with a soap free and slightly damp cloth. Then dry the surface with a dry cotton towel. Avoid aggressive and ammonia containing substances at all times when cleaning.

Periodic maintenance: Clean the surface 2 or 3 times per year with Natural Wood Cleaner and treat it with Wood Matt Polish for protection. Both products are from Oranje B.V.